



Citrix® NetScaler® 9.3 Quick Start Guide: SDX 17550/19550/20550/21550 Platform

Copyright and Trademark Notice

© CITRIX SYSTEMS, INC., 2011. ALL RIGHTS RESERVED. NO PART OF THIS DOCUMENT MAY BE REPRODUCED OR TRANSMITTED IN ANY FORM OR BY ANY MEANS OR USED TO MAKE DERIVATIVE WORK (SUCH AS TRANSLATION, TRANSFORMATION, OR ADAPTATION) WITHOUT THE EXPRESS WRITTEN PERMISSION OF CITRIX SYSTEMS, INC.

ALTHOUGH THE MATERIAL PRESENTED IN THIS DOCUMENT IS BELIEVED TO BE ACCURATE, IT IS PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE ALL RESPONSIBILITY FOR THE USE OR APPLICATION OF THE PRODUCT(S) DESCRIBED IN THIS MANUAL.

CITRIX SYSTEMS, INC. OR ITS SUPPLIERS DO NOT ASSUME ANY LIABILITY THAT MAY OCCUR DUE TO THE USE OR APPLICATION OF THE PRODUCT(S) DESCRIBED IN THIS DOCUMENT. INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE. COMPANIES, NAMES, AND DATA USED IN EXAMPLES ARE FICTITIOUS UNLESS OTHERWISE NOTED.

The following information is for FCC compliance of Class A devices: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio-frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case users will be required to correct the interference at their own expense.

Modifying the equipment without Citrix' written authorization may result in the equipment no longer complying with FCC requirements for Class A digital devices. In that event, your right to use the equipment may be limited by FCC regulations, and you may be required to correct any interference to radio or television communications at your own expense.

You can determine whether your equipment is causing interference by turning it off. If the interference stops, it was probably caused by the NetScaler Request Switch™ 9000 Series equipment. If the NetScaler equipment causes interference, try to correct the interference by using one or more of the following measures:

Move the NetScaler equipment to one side or the other of your equipment.

Move the NetScaler equipment farther away from your equipment.

Plug the NetScaler equipment into an outlet on a different circuit from your equipment. (Make sure the NetScaler equipment and your equipment are on circuits controlled by different circuit breakers or fuses.)

Modifications to this product not authorized by Citrix Systems, Inc., could void the FCC approval and negate your authority to operate the product.

BroadCom is a registered trademark of BroadCom Corporation. Fast Ramp, NetScaler, and NetScaler Request Switch are trademarks of Citrix Systems, Inc. Linux is a registered trademark of Linus Torvalds. Internet Explorer, Microsoft, PowerPoint, Windows and Windows product names such as Windows NT are trademarks or registered trademarks of the Microsoft Corporation. NetScape is a registered trademark of Netscape Communications Corporation. Red Hat is a trademark of Red Hat, Inc. Sun and Sun Microsystems are registered trademarks of Sun Microsystems, Inc. Other brand and product names may be registered trademarks or trademarks of their respective holders.

Software covered by the following third party copyrights may be included with this product and will also be subject to the software license agreement: Copyright 1998 © Carnegie Mellon University. All rights reserved. Copyright © David L. Mills 1993, 1994. Copyright © 1992, 1993, 1994, 1997 Henry Spencer. Copyright © Jean-loup Gailly and Mark Adler. Copyright © 1999, 2000 by Jef Poskanzer. All rights reserved. Copyright © Markus Friedl, Theo de Raadt, Niels Provos, Dug Song, Aaron Campbell, Damien Miller, Kevin Steves. All rights reserved. Copyright © 1982, 1985, 1986, 1988-1991, 1993 Regents of the University of California. All rights reserved. Copyright © 1995 Tatu Ylonen, Espoo, Finland. All rights reserved. Copyright © UNIX System Laboratories, Inc. Copyright © 2001 Mark R V Murray. Copyright 1995-1998 © Eric Young. Copyright © 1995, 1996, 1997, 1998. Lars Fenneberg. Copyright © 1992. Livingston Enterprises, Inc. Copyright © 1992, 1993, 1994, 1995. The Regents of the University of Michigan and Merit Network, Inc. Copyright © 1991-2, RSA Data Security, Inc. Created 1991. Copyright © 1998 Juniper Networks, Inc. All rights reserved. Copyright © 2001, 2002 Networks Associates Technology, Inc. All rights reserved. Copyright (c) 2002 Networks Associates Technology, Inc. Copyright 1999-2001© The Open LDAP Foundation. All Rights Reserved. Copyright © 1999 Andrzej Bialecki. All rights reserved. Copyright © 2000 The Apache Software Foundation. All rights reserved. Copyright (C) 2001-2003 Robert A. van Engelen, Genivia inc. All Rights Reserved. Copyright (c) 1997-2004 University of Cambridge. All rights reserved. Copyright (c) 1995. David Greenman. Copyright (c) 2001 Jonathan Lemon. All rights reserved. Copyright (c) 1997, 1998, 1999. Bill Paul. All rights reserved. Copyright (c) 1994-1997 Matt Thomas.

All rights reserved. Copyright © 2000 Jason L. Wright. Copyright © 2000 Theo de Raadt. Copyright © 2001 Patrik Lindergrén.

All rights reserved.

Last Updated: August 2011

Document code: December 1 2011 05:30:41

Quick Installation and Configuration

Welcome to the Citrix NetScaler Application Delivery product line.

Please review the following information before proceeding with installation of the SDX appliance.

Before you Begin

Verify that the following components and accessories are included:

- ♦ One NetScaler SDX appliance
- ♦ One accessory kit that contains:
 - One RJ-45 to DB-9 adapter
 - One 6 ft RJ-45/DB-9 cable
 - Two power cables for the SDX 11500/13500/14500/16500/18500/20500, SDX 17500/19500/21500, and SDX 17550/19550/20550/21550 appliances .

Note: Make sure that a power outlet is available for each cable.

- ♦ One mounting rail kit


Note: SFP and SFP+ transceivers are sold separately. Contact your Citrix sales representative to order transceivers for your appliance. Only transceivers supplied by Citrix are supported on the appliance.

Citrix NetScaler SDX 17550, SDX 19550, SDX 20550, and SDX 21550

The Citrix NetScaler models SDX 17550, SDX 19550, SDX 20550, and SDX 21550 are 2U appliances. Each model has two 6-core processors for a total of 12 physical cores (24 cores with hyper-threading), and 96 gigabytes (GB) of memory.


The following figure shows the front panel of the SDX 17550/19550/20550/21550 appliance.

Figure 1-1. Citrix NetScaler SDX 17550/19550/20550/21550 appliance, front panel



The following figure shows the back panel of the SDX 17550/19550/20550/21550 appliance.

Figure 1-2. Citrix NetScaler SDX 17550/19550/20550/21550 appliance, back panel



Configuration Requirements

Determine the following information for performing the initial configuration.

- ◆ NetScaler SDX IP address and subnet mask: The management IP address and the mask used to define the subnet in which the SDX appliance is located. This IP address is used to access the NetScaler SDX management virtual machine (SVM).
- ◆ XenServer IP address: The IP address of the XenServer hypervisor.
- ◆ Default gateway: The IP address of the router that forwards traffic out of the appliance's subnet.
- ◆ Root password: The root user (nsroot) has full administrative privileges on the appliance. The root password is used to authenticate the root user.

Installation


Installation involves rack-mounting the appliance, installing transceivers (if available), and connecting the appliance to the network and a power source.

Note: The appliances illustrated in the installation instructions may not represent the actual NetScaler SDX appliance.

Rack Mounting a Citrix NetScaler SDX Appliance

The appliance is shipped with rack-rail hardware. This hardware consists of two inner rails that you attach to the appliance, one on each side, and a rack-rail assembly that you attach to the rack. The following figure illustrates the steps involved in mounting the Citrix NetScaler SDX appliance to a rack.

Figure 1-3. Rack Mounting the Appliance



Appliance Precautions

- ◆ Determine the placement of each component in the rack before you install the rail.
- ◆ Install the heaviest appliance first at the bottom of the rack, and then work upward. Distribute the load on the rack evenly. An unbalanced rack is hazardous.
- ◆ Allow the power supply units and hard drives to cool before touching them.
- ◆ Install the equipment near a socket outlet for easy access.
- ◆ Mount equipment into a rack with sufficient airflow for safe operation.
- ◆ For a closed or multi-unit rack assembly, the ambient operating temperature of the rack environment may be greater than the ambient temperature of the room. Therefore, consider the lowest and highest operating temperatures of the equipment when making a decision about where to install the appliance in the rack.

Rack Precautions

- ◆ Make sure that the leveling jacks on the bottom of the rack are fully extended to the floor, with the full weight of the rack resting on them.
- ◆ For a single-rack installation, attach a stabilizer to the rack.
- ◆ For a multiple-rack installation, couple (attach) the racks together.
- ◆ Always make sure that the rack is stable before extending a component from the rack.
- ◆ Extend only one component at a time. Extending two or more simultaneously may cause the rack to become unstable.
- ◆ The handles on the left and right of the front panel of the appliance should only be used for extending the appliance out of the rack. These handles should not be used

for mounting the appliance on the rack. Rack-rail hardware described later should be used instead.

Installing Transceivers

The SDX appliances support only fiber transceivers in the 10GE ports.

Warning: Only those transceivers provided by Citrix Systems, Inc. are supported. You must not attempt to install third-party transceivers. Doing so voids the warranty.

To install the transceiver

1. Carefully remove the transceiver from its box.
2. Align the transceiver to the front of the transceiver slot on the front panel of the appliance.
3. Hold the transceiver between your thumb and index finger and insert it into the transceiver slot, pressing it in until you hear the transceiver snap into place.
4. Lock the transceiver.

Connecting a NetScaler SDX Appliance to the Network

Connect the interfaces on the appliance to the network ports on the appropriate switches by using Ethernet/fiber optic cables.

Figure 1-4. Connecting a Citrix NetScaler SDX appliance to the network




Warning: Connecting multiple network ports to the same switch or VLAN can result in a network loop.

Note: By default, the NetScaler SDX appliance is configured to use auto-negotiation. When you install a NetScaler appliance for the first time, be sure to configure your other equipment to use auto-negotiation for the ports that are connected to the NetScaler appliance. After initial logon and configuration, you can choose to disable auto-negotiation.

Connecting a NetScaler SDX Appliance to a Power Source

Connect the power cable to one of the inlet receptacles on the back of the appliance and connect the other end of the power cable to a power outlet. If your appliance has a second power supply, repeat this process. All models function properly with a single power supply. The extra power supply on some models serves as a backup.

Figure 1-5. Connecting a Citrix NetScaler SDX appliance to a power source



Electrical Safety Precautions

Basic electrical safety precautions should be followed to protect yourself from harm and the appliance from damage.

- ♦ Be aware of the location of the emergency power off (EPO) switch. If an electrical accident occurs, you can quickly remove power to the appliance.
- ♦ Use a regulating uninterruptible power supply (UPS) to protect the appliance from power surges and voltage spikes, and to keep the appliance operating in case of power failure.
- ♦ Do not work alone when working with high voltage components.
- ♦ Always disconnect the appliance from power before removing or installing any component. When disconnecting power, you should first shut down the appliance and then unplug the power cords of all the power supply units connected to the appliance. As long as the power cord is plugged in, line voltages may be present in the power supply, even when the power switch is OFF.
- ♦ Do not use mats designed to decrease static electrical discharge as protection from electrical shock. Instead, use rubber mats that have been specifically designed as electrical insulators.
- ♦ Make sure that the power supply cords include grounding plugs and are plugged into grounded electrical outlets.
- ♦ Make sure that the power source can handle the appliance's maximum power consumption rating with no danger of an overload.
- ♦ A reliable ground must be maintained at all times. Therefore, the rack should be grounded. Pay particular attention to power supply connections other than the direct connection to the branch circuit (for example, connections to power strips).

Setting Up Connectivity

Connect the appliance to a management workstation or the network by using the NetScaler SDX Management Service user interface.

User Interface Setup

To set up the appliance by using the Management Service user interface, connect a workstation or laptop to the same network as the appliance. Citrix recommends that you change the password of the nsroot user.

To configure the NetScaler SDX appliance by using the Management Service user interface

1. Connect the NetScaler SDX appliance to a management workstation or network by using interface 0/1.
2. Open a browser and type: `http://192.168.100.1`

Note: The NetScaler SDX Management Service is preconfigured with the IP address 192.168.100.1 and the XenServer hypervisor is preconfigured with the IP address 192.168.100.2.

3. In the **User Name** box, type `nsroot`.
4. In the **Password** box, type `nsroot`.
5. In the navigation pane, click **System**.
6. In the details pane, under **System Administration**, click **Network Configuration** and enter values for the following parameters:
 - **Interface***—The management interface that connects the appliance to a management workstation or network. Possible values: 0/1, 0/2. Default: 0/1.
 - **XenServer IP Address***—The IP address of the XenServer.
 - **Management VM IP Address***—The IP address that is used to access the management VM by using a Web browser.

Note: The XenServer IP address and management VM IP address should be in the same subnet.

- **Netmask***—The mask used to define the subnet in which the SDX appliance is located.
- **Gateway***—The IP address of the router that forwards traffic out of the appliance's subnet.
- **DNS Server**—The IP address of the DNS server.

*A required parameter

7. Click **OK**, and then click **Close**.
8. To confirm that the NetScaler SDX appliance is configured correctly, you can either ping the new SDX Management Service IP (SVM IP) address or use the new SVM IP address to open the user interface in a browser.

Note: After changing the network configuration, close all browser instances and open a new browser instance to access the appliance.

To change the password of the system user by using the Management Service user interface

1. In the navigation pane, expand **System**, and then click **Users**.
2. In the details pane, select **nsroot user**, and then click **Modify**.
3. In the **Configure System User** dialog box, type the new password for the user.
4. Confirm the password by typing it again.
5. Click **OK**, and then click **Close**.

Configuring the LOM Port

For initial configuration of the LOM port, connect to the port's default IP address and change it to the address that you want to use for remote monitoring and management. Also specify the administrator credentials and the network settings.

Note: The LEDs on the LOM port are unoperational by design.

To configure the LOM port

1. In a Web browser, type the IP address of the LOM port. For initial configuration, type the port's default address: `http://192.168.1.3`
2. In the **User Name** and **Password** boxes, type the administrator credentials. You can obtain the initial user name and password from your sales representative or from Citrix Customer Service.
3. In the Menu bar, click **Configuration**.
4. Under **Options**, click **Network** and type values for the following parameters:
 - IP Address—The IP address of the LOM port.
 - Subnet Mask—The mask used to define the subnet of the LOM port.
 - Default Gateway—The IP address of the router that connects the appliance to the network.

5. Click **Save**.

Power Cycling the Appliance

You can remotely turn off the appliance and turn it back on. The result is similar to pressing the power button on the back panel of the appliance for less than four seconds.

Note: Power cycling the appliance by using the LOM port is not supported in the current release.

To power cycle the appliance

1. In a Web browser, type the IP address of the LOM port.
2. In the **User Name** and **Password** boxes, type the administrator credentials.
3. In the **Menu** bar, click **Remote Control**.
4. Under **Options**, click **Power Control**, and then click **Power Cycle Server**.
5. Click **Perform Action**.

System Specifications

The following table summarizes the specifications of the NetScaler SDX 17550/19550/20550/21550 appliances.

Specifications	SDX 17550/19550/20550/21550
Processors	two 6-core processors for a total of 12 physical cores (24 cores with hyper-threading)
Memory	96 GB
Number of power supplies	2
AC power supply input voltage, frequency, and current	100-240 VAC 50-60 Hz 6.5-3.5 A
Maximum power consumption	850 W

Specifications	SDX 17550/19550/20550/21550
Heat dissipation	2900 BTU per hour
Weight	40 lbs
Height	2U
Width	EIA 310-D for 19-inch racks
Depth	24.75 in or 62.865 cm
Operating temperature (degree Celsius)	0-40
Humidity range (non-condensing)	5%-95%
Safety certifications	TUV
EMC & susceptibility	FCC (Part 15 Class A), CE, C-Tick, VCCI-A
Environmental compliance	RoHS, WEEE

Additional Information

A complete set of documentation is available on the **Documentation** tab of your NetScaler SDX appliance and from <http://support.citrix.com/>. (Most of the documents require Adobe Reader, available at <http://adobe.com/>.)

To view the documentation

1. From a Web browser, log on to the NetScaler SDX appliance.
2. Click the **Documentation** tab.
3. To view a short description of each document, hover your cursor over the title. To open a document, click the title.

If you have support questions, please contact Citrix Technical Support at 1-800-4-CITRIX (1-800-424-8749). For additional contact information, see Support Phone Numbers at <http://support.citrix.com/>. If you have comments or feedback on this documentation, please email to nsdocs_feedback@citrix.com.